

ECBT2.E144392**Connectors for Use in Data, Signal, Control and Power Applications - Component**[Page Bottom](#)**Connectors for Use in Data, Signal, Control and Power Applications - Component**[See General Information for Connectors for Use in Data, Signal, Control and Power Applications - Component](#)**NELTRON INDUSTRIAL CO LTD**

E144392

2ND FL

184 CHENG-TEH RD, SEC 4

SHIH-LIN, TAIPEI 111 TAIWAN

Wire to board connectors, Cat. Nos. 1311, 1310 and 5289H, followed by -02 through -15; Cat. Nos. 8982H, 8980H and 8981H, followed by -04; Cat. Nos. 2417SJ, 2417RJ, 2418HJ, 2317SJ, 2317RJ, 2317SB, 2317RB, 2318HJ and 2318HB, followed by -02 through -15; Cat. No. 2226A, followed by -01 through -40; Cat. No. 2226B, followed by -02 through -80; Cat. No. 2221, followed by -06, -12; Cat. No. 2222, followed by -06; Cat. No. 2220, followed by -02 through -16; Cat. Nos. 2219S, 2219R, 2217S and 2217R, followed by -02 through -15; Cat. No. 2218H, followed by -01 through -15; Cat. No. 2026A, followed by -01 through -40; Cat. No. 2026B, followed by -02 through -80; Cat. No. 4400, followed by -44; Cat. No. 4401, followed by -10, -14, -16, -20, -24, -26, -30, -34, -40, -50, -60, -64; Cat. No. 4402, followed by -10, -14, -16, -20, -26, -34, -40, -44, -50, -60, -64; Cat. No. 4403, followed by -10, -14, -16, -20, -26, -30, -34, -40, -50, -60; Cat. No. 4404, followed by -14, -16, -18, -20; Cat. No. 4405, followed by -10, -14, -16, -20, -26; Cat. No. 4406, followed by -10, -14, -16, -20, -24, -26, -30, -34, -40, -50, -60, -64; Cat. No. 4501, followed by -20, -26, -32, -34, -40, -50, -52, -60, -68, -80, -100; Cat. No. 1200, followed by -03 through -09; Cat. No. 1005 followed by -50, -100; Cat. No. 2162, followed by -16, -18, -20, -24; Cat. No. 2227, followed by -08, -14, -16, -18, -20, -24, -28, -40; Cat. No. 6605, followed by -72; Cat. No. 6602, followed by -30, -60; Cat. Nos. 1007 and 1008, followed by -14, -20, -26, -30, -40, -50, -60, -68, -80, -100; Cat. No. 6601, followed by -20, -28, -32, -44, -52, -68, -84; Cat. No. 6603, followed by -68, -84, -85, -114, -121, -132; Cat. No. 1201 followed by -03 through -08; Cat. No. 1202, followed by -05; Cat. No. 2416S, followed by -20, -26, -32, -34, -40, -50, -52, -60, -68, -80, -100; Cat. Nos. 2216S and 2216R, followed by -10, -12, -14, -16, -20, -24, -26, -30, -34, -40, -50, -56, -60, -64; Cat. Nos. 2516S and 2516R, followed by -20, -26, -32, -34, -40, -50, -52, -60, -68, -80, -100; Cat. Nos. 2223S and 2223R, followed by -02 through -21; Cat. No. 2323S, followed by -02 through -20; Cat. No. 2316S, followed by -10, -14, -16, -20, -26, -30, -34, -40, -50, -60, -64; Cat. No. 2525, followed by -10, -12, -20, -30, -40, -50, -60, -80, -100, -120; Cat. No. 2314S, followed by -20, -26, -32, -34, -40, -50, -52, -60, -68, -80, -100; Cat. No. 2224, followed by -02 through -15; Cat. Nos. 2211S and 2211R, followed by -01 through -40; Cat. Nos. 2213S and 2213R, followed by -02 through -80; Cat. No. 2212S, followed by -02 through -40; Cat. No. 2214S, followed by -02 through -80; Cat. Nos. 2215S and 2215R, followed by -10, -12, -16, -18, -20, -26, -30, -34, -40, -50, -60; Cat. No. 2225, followed by -36, -44, -50, -62, -80, -86, -100; Cat. No. 2207S, followed by -02 through -80; Cat. Nos. 2208S and 2208R, followed by -02 through -80; Cat. No. 2209S, followed by -01 through -40; Cat. Nos. 2210S and 2210R, followed by -01 through -40; Cat. Nos. 2206S, followed by -01 through -30; Cat. No. 41612, followed by -32, -48, -64, -96; Cat. Nos. 2205 and 2228, followed by -02; Cat. No. 8182, followed by -04; Cat. Nos. 5005 and 5006, followed by -01, -02, -03, -04A, -04B, -05, -06, -09, -12, -15; Cat. Nos. 5514R and 5514P, followed by -13; Cat. Nos. 5512S and 5512P, followed by -15, -26, -44, -62; Cat. No. 5511, followed by -09, -15, -25; Cat. No. 5510, followed by -15; Cat. Nos. 5509S and 5509P, followed by -15, -26, -62; Cat. Nos. 5508S and 5508P followed by -15, -26, -44, -62; Cat. Nos. 5506S and 5506P, followed by -09, -15, -25, -37; Cat. Nos. 5504PF1, 5504SF1, 5504SF2, 5505F1, 5505F2, 5503S and 5503P, followed by -09, -15, -25, -37; Cat. Nos. 5501S, 5501P and 5502, followed by -09, -15, -19, -23, -25, -37, -50; Cat. No. 5701, followed by -14, -24, -36; Cat. Nos. 5702, 5703 and 5706, followed by -40; Cat. No. 5704, followed by -30; Cat. No. 5707, followed by -20; Cat. Nos. 1109, 1111 and 1113, followed by -21; Cat. Nos. 1009, 1011 and 1013, followed by -21; Cat. Nos. 1114R and 1114S, followed by -21.

Connectors, Model No. 1002S followed by 30, 40, 50, 60 or 68; Model No. 1003-P-50; Model No. 1010 followed by 50 or 68, followed by P-PN; Model No. 1211 followed by 04, 06 or 08, followed by 04, 06 or 08; Model No. 1223 followed by -04 thru 30, followed by 02 or 03; Model No. 1224S followed by 04 thru 27; Model No. 1224SM followed by 04 thru 30; Model No. 1230S followed by 04 thru 15; Model No. 1230R followed by 04 thru 30; Model No. 1250HM followed by 02 thru 15; Model No. 1251SM followed by 02 thru 15; Model No. 1251RM followed by 02 thru 15; Model No. 1251S followed by 02 thru 15, followed by SMD; Model No. 1251R followed by 02 thru 15, followed by SMD; Model No. 1310H followed by 02 thru

15; Model No. 1394-06; Model No. 1778 followed by 16, 20, 22, 24, 28, 30, 32, 40, 42, 48, 52, 54, 56 or 64, followed by 03, 04 or 06; Model No. 1778MC followed by 16, 20, 24, 28, 30, 40, 42, 48, 52, 56 or 64, followed by 03, 04, 06 or 075; Model No. 1999P followed by 04 thru 80; Model No. 1999S followed by 04 thru 120, followed by A1, A2 or A3, followed by B1, B2 or B3; Model No. 2006H followed by 01, thru 06; Model No. 2006S followed by 01 thru 05; Model No. 2010 followed by 10 thru 12, followed by H1, H2, H3 or H4; Model No. 2011-10; Model No. 2016 followed by 10, 12, 14, 16, 20, 22, 24, 26, 30, 34, 36, 40, 44, 50, 60, 64 or 68; Model No. 2018 followed by P or R, followed by 02 thru 12; Model No. 2099P followed by 04 thru 10; Model 2099S followed by 04 thru 14; Model No. 2100P followed by 06 thru 20; Model 2100S followed by 04 thru 10; Model No. 2110 followed by 20, 30, 40, 50, 60, 80 or 100, followed by 34 or 44, followed by MM; Model No. 2114 followed by R, H or S, followed by 02 thru 10; Model No. 2150-08; Model No. 2198S followed by 10, 24, 30, 40, 44, 50, 60, 70, 80, 90 or 100, followed by A1 or A2; Model No. 2199SA followed by 04 thru 30, followed by 01 thru 03; Model No. 2199SB followed by 02 thru 10, followed by A1, A2 or A3, followed by B1 or B2, followed by C1 or C2; Model No. 2199R followed by 0 or 5, followed by 04 thru 30, followed by A1, A2 or A3, followed by B1 or B2, followed by C1 or C2; Model No. 2200SA followed by 05 thru 50, followed by A1 or A2; Model No. 2200SB followed by 10 thru 50, followed by A1 or A2; Model No. 2204 followed by S or R, followed by 02 thru 30; Model No. 2206SA followed by 01 thru 36, followed by 46; Model No. 2206SB followed by 02 thru 16, followed by 46; Model No. 2206PA followed by 01 thru 36, followed by 739; Model No. 2206PB followed by 02 thru 50, followed by 739; Model No. 2227MC followed by 06, 08, 10, 14, 16, 18, 20, 22, 24, 28, 32, 36, 40, 42, 48 or 64, followed by 03, 06 or 09; Model No. 2233 followed by S or R, followed by 03 thru 120; Model No. 2317 followed by SEH or REH, followed by 02 thru 15; Model No. 2317 followed by RM or SM, followed by 02 thru 10; Model No. 2318 followed by HM or HEH, followed by 02 thru 15; Model No. 2323 followed by R or S, followed by 04 thru 23, followed by A or B; Model No. 1016 followed by 09 or 15; Model No. 2007H followed by 02 thru 06; Model No. 2007S followed by 02 thru 05; Model No. 2324S followed by 04 thru 22; Model No. 2324R followed by 03 thru 30; Model No. 2392-5100; Model No. 2417 followed by SB or RB, followed by 02 thru 08; Model No. 2418HB followed by 02 thru 15; Model No. 3750R followed by 02 thru 12; Model No. 3750S followed by 02 or 03; Model No. 3920 followed by 02, 03, 04, 06, 09 or 12; Model No. 3921 followed by 02, 03, 04, 06, 09 or 12; Model No. 41815 followed by R, S or BE, followed by 02 thru 10; Model No. 4407 followed by 10, 14, 16, 20, 26, 34, 40, 50, 60 or 64; Model No. 4408 followed by 10, 12, 16, 20, 24, 26, 30, 34, 40 or 44; Model Nos. 5075AS-04, 5075BR-04, 5075AR-08B, 5075AR-04; Model No. 5197H followed by 02 thru 12; Model No. 5197 followed by S or R, followed by 02 thru 04, may be followed by 01; Model No. 5504F3-09P; Model No. 5513S followed by 3W3, 5W1, 7W2, 8W8, 11W1 or 13W3; Model No. 5515-13W3; Model No. 5557 followed by 02, 04, 06, 08, 10, 12, 14, 16, 18 or 20; Model No. 5559 followed by 02, 04, 06, 08, 10, 12 or 14; Model No. 5566S followed by 02, 04, 06, 08, 10, 12, 14, 16, 18 or 20; Model No. 5569R followed by 02, 04, 06, 08, 10, 12, 14, 16, 18 or 20, may be followed by 01; Model No. 6127 followed by S or P, followed by 02 thru 31; Model No. 6604P followed by 01 thru 40, followed by 9.1, 10.0, 10.6, 12.1 or 13.7; Model No. 6604S followed by 01 thru 40, may be followed by WR; Model No. 6610-321; Model No. 6610P-321, 6615-168-LE; Model No. 8981 followed by SA, SM or R, followed by 04; Model No. 8982S followed by 02 thru 08; Model No. SQJ followed by 24S, 26S, 28S, 28L, 32S or 40L; Model No. 4410-40.

Models 5589, 5321, 5592, 5594.

Cat. No. 1223, followed by 03 thru 32, followed by T or G; Cat. No. 1224R, followed by 03 thru 30; Cat. No. 1226, followed by 04 thru 50, followed by T or G; Cat. No. 1227, followed by S, R or SM, followed by 03 thru 30; Cat. No. 1253R, followed by 02 thru 16, 18, 20, 22, 24, 26, 28 or 30, followed by T or G; Cat. No. 1255R, followed by 02 thru 15, 20, 25 or 30; Cat. No. 1600, followed by S or R, followed by 02 thru 15 or 20, followed by T or G; Cat. Nos. 2000P, 2001S, followed by 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32, 34, 36, 38, 40, 50, 60, 70, 80, 100, 120, followed by G; Cat. No. 2017, followed by SM, S or R, followed by 10, 12, 14, 16, 20, 22, 24, 26, 30, 34, 40, 44, 50, 60, followed by G; Cat. Nos. 2208, 2213, followed by DI, S, R, SM or SMDI, followed by 02, 04, 06, 08, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32, 34, 36, 38, 40, 42, 44, 46, 48, 50, 52, 54, 56, 58, 60, 62, 64, 66, 68, 70, 72, 74, 76, 78 or 80, followed by G, T or SG; Cat. No. 2209, followed by SM1, SM or S, followed by 2 thru 15, 18, 20, 23, 25, 28, 30, 33, 35, 38 or 40, followed by G, SG, SV or T; Cat. No. 2210, followed by DI, S, R, SM or SMDI, followed by 02, 04, 06, 08, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32, 34, 36, 38 or 40, followed by G, T or SG; Cat. No. 2212TBA, followed by 01 thru 40, followed by G; Cat. Nos. 2214R, 2214TBA, followed by 04, 06, 08, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32, 34, 36, 38, 40, 42, 44, 46, 48, 50, 52, 54, 56, 58, 60, 62, 64, 66, 68, 70, 72, 74, 76, 78 or 80, followed by G; Cat. Nos. 2217R1, 2217S1, followed by 02 thru 20, followed by T or G; Cat. Nos. 2217R2, 2217S2, followed by 02, 04, 06, 08, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32, 34, 36, 38 or 40, followed by T or G; Cat. No. 2316, followed by SM, R or S, followed by 06, 08, 10, 12, 14, 16, 20, 24, 26, 30, 34 or 40, followed by G, T or SG; Cat. Nos. 4409AP, 4409A, 4409, 4409SM, followed by 04, 06, 08, 10, 12, 14, 16, 18, 20, 22, 24 or 26.

Low voltage connectors, Cat. No. 2350SM-02.

Cat. No. 1225SM followed by 20, followed by 01; Cat. No. 1226 followed by 30, followed by 02 or 03; Cat. No. 1254SMB followed by 10, 20, 30 or 40; Cat. Nos. 1394S-06, 1394R-06; Cat. No. 1394SM followed by 04; Cat. No. 1394UR followed by 06; Cat. No. 1500 followed by S or R, followed by 2 thru 10; Cat. No. 2000P, followed by 14G, 20G, 30G, 32G, 36G, 40G or 50G, followed by 233; Cat. No. 2001S, followed by 14G, 20G, 30G, 32G, 36G, 40G or 50G, followed by 220; Cat. No. 2212BR followed by 30, followed by G or T; Cat. No. 2212SM followed by 40G, followed by 75; Cat. No. 2214SM followed by 70G, followed by 75; Cat. No. 2214BR followed by 26, followed by G or T; Cat. No. 2214DS followed by 20, followed by 66; Cat. No. 2214TB followed by 2, 4, 6, 8, 10, 12, 14, 16, 18 or 20; Cat. No. 2214113 followed by 64G, followed by 1A, 1B, 2B, 3B, 1C, 2C, 3C or 4C; Cat. No. 2227P followed by 20G, 24G, 28 or 32G, followed by 03 or 06; Cat. No. 2228P followed by 2 thru 10; Cat. No. 2234S followed by 96; Cat. No. 2316113 followed by 64G, followed by A, B or C; Cat. No. 231682-3404 followed by 001 thru 006; Cat. No. 2317 followed by SD or RD, followed by 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15 or 16; Cat. No. 2325 followed by 18/36, 20/40, 22/44, 28/56, 30/60, 36/72, 40/80, 43/86 or 50/100, followed by L1 or L2; Cat. No. 2392-5100; Cat. No. 2400SM followed by 02, 03 or 04, maybe followed by T1, T2 or

T3; Cat. No. 2417 followed by SJ or RJ, followed by 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30 or 32, followed by PHD; Cat. No. 2425 followed by 40, 44, 56, 60, 86 or 100, followed by L1 or L2; Cat. No. 2525 followed by 200; Cat. No. 2526-242-SLOT1; Cat. No. 2710-06 followed by one alphanumeric digit; Cat. No. 4110SM followed by 07, followed by A1, A2 or A3, followed by M; Cat. No. 4120SM followed by 09; Cat. No. 4130SM followed by 10; Cat. Nos. 5075BMR-04-SM, 5075BMR-05-SM, 5075AMR1-04-SM; Cat. No. 5075BS followed by 04, followed by WH; Cat. No. 5075AUR followed by 04; Cat. Nos. 5075ARP-04, 5075ARP-04-SMD; Cat. No. 5198 followed by S or R, followed by 2 thru 10; Cat. No. 6604SB followed by 40WR; Cat. No. 6801S followed by 50, followed by 70; Cat. No. 6831S followed by 40; Cat. No. 7520SL followed by 50P, followed by A, B, C or D; Cat. No. 7520 followed by 50P, followed by T1B3; Cat. Nos. ICA-501-006, ICA-501-008.

Cat. No. 1320H followed by 02 thru 12; Cat. No. 5560 followed by 02, 04, 06, 08, 10, 12, 14, 16 or 18; Cat. No. 5561 followed by 02, 04, 06, 08, 10, 12, 14, 16 or 18; Cat. No. 5561S followed by 02, 04, 06, 08, 10, 12, 14, 16, 18; Cat. No. 5561R followed by 02, 04, 06, 08, 10, 12, 14, 16 or 18, followed by T, followed by SM or SM1; Cat. No. 5561R followed by 02, 04, 06, 08, 10, 12, 14, 16, 18; Cat. No. 5561R followed by 02, 04, 06, 08, 10, 12, 14, 16 or 18, followed by T, followed by SM, SM1 or SM2; Cat. No. 9200P followed by 4B, 6, 9, 12 or 15; Cat. No. 9200R followed by 4B, 6, 9, 12 or 15; Cat. No. 9635P, followed by 09, 12 or 15; Cat. No. 9635R followed by 09, 12 or 15; Cat. No. 2363P followed by 01, 02, 06, 04, 05, 06, 09, 12 or 15, followed by A, followed by 01 or blank; Cat. No. 2363R followed by 01, 02, 06, 04, 05, 06, 09, 12 or 15, followed by A, followed by 01; Cat. Nos. 2650P-08, 2650R-08.

Cat. No. 1320H, followed by 02 thru 12; Cat. No. 5560, followed by 02, 04, 06, 08, 10, 12, 14, 16 or 18; Cat. No. 5561, followed by 02, 04, 06, 08, 10, 12, 14, 16 or 18; Cat. No. 5561S, followed by 02, 04, 06, 08, 10, 12, 14, 16, 18; Cat. No. 5561R, followed by 02, 04, 06, 08, 10, 12, 14, 16 or 18, followed by T, followed by SM or SM1; Cat. No. 5561R, followed by 02, 04, 06, 08, 10, 12, 14, 16, 18; Cat. No. 5561R, followed by 02, 04, 06, 08, 10, 12, 14, 16 or 18, followed by T, followed by SM, SM1 or SM2; Cat. No. 9200P, followed by 4B, 6, 9, 12 or 15; Cat. No. 9200R, followed by 4B, 6, 9, 12 or 15; Cat. No. 9635P, followed by 09, 12 or 15; Cat. No. 9635R, followed by 09, 12 or 15; Cat. No. 2363P, followed by 01, 02, 06, 04, 05, 06, 09, 12 or 15, followed by A, followed by 01 or blank; Cat. No. 2363R, followed by 01, 02, 06, 04, 05, 06, 09, 12 or 15, followed by A, followed by 01; Cat. Nos. 2650P-08, 2650R-08.

Connectors, Cat. No. 1253H, followed by 02 thru 16, 18, 20, 22, 24, 26, 28 or 30; Cat. Nos. 1254HA, 1254RA, 1254SA and 2114H, followed by 02 thru 15; Cat. No. 1254HB, followed by 10, 20, 30 or 40; Cat. No. 1255H, followed by 02 thru 10, 12, 20, 25 or 30; Cat. No. 1600H and 2220H, followed by 02 thru 20; Cat. No. 1600HB and 1600RMB, followed by 20, 30, 40 or 50; Cat. No. 1600SMB, followed by 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 40 or 50, followed by CR or blank; Cat. No. 1602H, followed by 08, 14, 20 or 30; Cat. Nos. 2004P and 2004S, followed by 10, 14, 16, 20, 24, 26, 30, 32, 34, 36, 40, 46, 50, 60, 70 or 80, followed by G; Cat. Nos. 2005P and 2005S, followed by 31 or 41; Cat. Nos. 2010 and 2011, followed by 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32, 34, 36, 38, 40, 50, 60, 68, 70, 80, 90, followed by G; Cat. Nos. 2065P and 2065S, followed by 10, 20, 30, 40, 50 or 52, followed by G; Cat. Nos. 2199RA and 2199SA, followed by 02 thru 50, followed by G; Cat. Nos. 2199R0 and 2199R5, followed by 02, 04, 06, 08, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32, 34, 36, 38, 40, 42, 44, 46, 48, 50, 52, 54, 56, 58, 60, 62, 64, 66, 68, 70, 72, 74, 76, 78, 80, 82, 84, 86, 88, 90, 92, 94, 96, 98 or 100, followed by G; Cat. Nos. 2199SB and 2200SB, followed by 04, 06, 08, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32, 34, 36, 38, 40, 42, 44, 46, 48, 50, 52, 54, 56, 58, 60, 62, 64, 66, 68, 70, 72, 74, 76, 78, 80, 82, 84, 86, 88, 90, 92, 94, 96, 98, 100, followed by G; Cat. No. 2207SM, followed by 04, 06, 08, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32, 34, 36, 38, 40, 42, 44, 46, 48, 50, 52, 54, 56, 58, 60, 62, 64, 66, 68, 70, 72, 74, 76, 78 or 80, followed by G; Cat. No. 2211, followed by DI or SM, followed by 02 thru 40, followed by G, T or SG; Cat. No. 2212111, followed by 02 thru 40, followed by G, followed by 1A, 1B, 1C, 2B, 2C, 3B, 3C or 4C; Cat. Nos. 2212R and 2212TB, followed by 02 thru 40, followed by G, SG or T; Cat. No. 2801SM, followed by 02 thru 05, followed by G; Cat. Nos. 5560A and 5561A, followed by 02 thru 12; Cat. No. 4409AS, followed by 04, 06, 08, 10, 12, 14, 16, 18, 20, 22, 24 and 26; Cat. No. 5075ABMR, followed by 05, followed by SM or SM1; Cat. Nos. 5198H, followed by 02 thru 10; Cat. No. 5289, followed by R or S, followed by 02 thru 12; Cat. No. 5504F1RS, followed by 09, 15, 25 or 37, followed by S; Cat. Nos. 5513P-13W3, 5513S-13W3, 5514P-13W3, 5514S-13W3, 5515P-13W3 and 5515S-13W3; Cat. Nos. 5518R-24-1M15, 5518R-24-5M15, 5518S-24-5M15; Cat. No. 6604PB, followed by 04, 06, 08, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32, 34, 36, 38, 40, 42, 44, 46, 48, 50, 52, 54, 56, 58, 60, 62, 64, 66, 68, 70, 72, 74, 76, 78 or 80, followed by G or T; Cat. Nos. 6803S and 6832S, followed by 04, 06, 08, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32, 34, 36, 38, 40, 42, 44, 46, 48, 50, 52, 54, 56, 58, 60, 62, 64, 66, 68, 70, 72, 74, 76, 78 or 80, followed by G, SG or T; Cat. Nos. 6831S and 7801R, followed by 02 thru 40; Cat. No. 6833S, followed by 04, 06, 08, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32, 34, 36, 38, 40, 42, 44, 46, 48, 50, 52, 54, 56, 58, 60, 62, 64, 66, 68, 70, 72, 74, 76, 78 or 80; Cat. No. 6850, followed by R, S or SM, followed by 02 thru 50, followed by G or T; Cat. No. 6852, followed by R1 or S1, followed by 04, 06, 08, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32, 34, 36, 38, 40, 42, 44, 46, 48, 50, 52, 54, 56, 58, 60, 62, 64, 66, 68, 70, 72, 74, 76, 78 or 80, followed by G or T; Cat. No. 6853, followed by R1 or S1, followed by 04, 06, 08, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32, 34, 36, 38, 40, 42, 44, 46, 48, 50, 52, 54, 56, 58, 60, 62, 64, 66, 68, 70, 72, 74, 76, 78 or 80; Cat. No. 8982R, followed by 02 thru 04.

Cat. No. 1252H followed by 02 thru 06; Cat. Nos. 1501H, 1501R followed by 02 thru 13; Cat. Nos. 1601H, 1601R followed by 20 or 30; Cat. No. 1602H followed by 08, 14, 20 or 30; Cat. Nos. 2006W, 2007W followed by 01 thru 06; Cat. No. 2217 followed by RMX or SMX, followed by 02 thru 20; Cat. Nos. 2257A, 2259A, 2266SA, 2269RA followed by 02 thru 06; Cat. Nos. 2257, 2259, 2266S, 2269R followed by 02, 04, 06, 08, 10, 12, 14, 16, 18, 20, 22 or 24; Cat. Nos. 2350H-02, 5075MMR-08A-F7, 5090R-19G, 8981S-04; Cat. No. 2400H followed by 02, 03 or 04; Cat. Nos. 3750G, 3750C, 3750A, followed by 02, 04, 06, 08, 10, 12, 14, 16, 18 or 20; Cat. No. 3750H followed by 02, 03 or 04; Cat. No. 6830S followed by 02 thru 40, followed by G; Cat. No. 6851S followed by 02 thru 50; Cat. Nos. 9635R, 9635S, 9635P followed by 02 thru 10, 12 or 15.

Cat. Nos. 8920H, 8920S followed by 02, 03, 04 or 05, followed by T, G or SG.

Connectors, Cat. No. 1500H, followed by 02 thru 15; Cat. No. 2105, followed by BG or GG, followed by BU, GN, RD, WH, YL or blank, followed by F4; Cat. No. 2200TB, followed by 04, 06, 08, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32, 34, 36, 38, 40, 42, 44, 46, 48, 50, 52, 54, 56, 58, 60, 62, 64, 66, 68, 70, 72, 74, 76, 78 or 80, followed by G, followed by SM, followed by 23; Cat. No. 2207TB, followed by 04, 06, 08, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32, 34, 36, 38, 40, 42, 44, 46, 48, 50, 52, 54, 56, 58 or 60, followed by G, followed by SM, followed by 24; Cat. No. 2217RR, followed by 02 thru 20; Cat. No. 5005S, followed by 06, followed by 01 or blank; Cat. Nos. 5075BMS-05, 5080H-15SG, 5080HS-22SG, 5081RR-07SG-A1 and 5081S-22SG.

NELTRON

Marking: Company name or trademark and catalog or model designation.

[Last Updated](#) on 2009-05-27

[Questions?](#)

[Notice of Disclaimer](#)

[Page Top](#)

[Copyright ?2009 Underwriters Laboratories Inc.®](#)

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL's Follow-Up Service. Only those products bearing the UL Mark should be considered to be Listed and covered under UL's Follow-Up Service. Always look for the Mark on the product.

UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Designs and/or Listings (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from the Online Certifications Directory with permission from Underwriters Laboratories Inc." must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "Copyright © 2009 Underwriters Laboratories Inc.®"